CHRISTINA®
WATCHES
*Swiss Made*

# USER MANUAL - MODEL 124

ETA G15.211

CHRISTINA®
WATCHES
*Swiss Made*

# USER MANUAL - MODEL 124

## A DISPLAY

**Watch hands**




## B SETTING THE TIMERS TO ZERO

**Setting crown in position II or III**


Set the hand of the 60 seconds timer to zero
Setting crown
Set the hand of the 1/10 second timer to zero
Set the hand of the 30 minutes timer to zero

## C CORRECTION MODE

**Setting the time**
**Correction of date**




**Note**
Setting crown in position **III: STOP-SECOND**

## D TIMING MODE

**Simple timing function**




1 to 3 order of functions

**WARNING**
Before starting the time, put back the chronograph hands to their original position.
If necessary, see paragraph SETTING THE TIMERS TO ZERO

CHRISTINA®
WATCHES
*Swiss Made*

# USER MANUAL - MODEL 124

## E TIMING MODE

**ADD function**



6 STOP **Read**
5 RESTART
4 STOP **Read**
3 RESTART
2 STOP **Read**
1 START
A
I
Setting crown in position **I**
B
X Reset to zero

1 to X order of functions

## F TIMING MODE

**SPLIT-TIME or INTERMEDIATE TIMES function**



START 1
A
I
Setting crown in position **I**
B



2
SPLIT 1
**Read time 1**
- 5 minutes
- 4 seconds
- 6/10 sec

A
I
B
RESTART 3
(catching-up)

1 to 3 order of functions

## G TIMING MODE

**SPLIT-TIME or INTERMEDIATE TIMES function (cont. and end)**

4
SPLIT 2
**Read time 2**
- 15 minutes
- 36 seconds
- 8/10 sec

A
I
B
RESTART 5
(catching-up)



A
6
STOP
**Read**
**LAST TIME**
- 25 minutes
- 18 seconds
- 4/10 sec

I
B
Reset 7
to zero

4 to 7 order of functions